

BKOOL

Thru Axle Fitment Guide: A4

By:  The Robert Axle Project


- 1) Print this sheet to it's actual size (do not scale or "fit to page"). Verify the accuracy of the scale below with a ruler.
- 2) Determine your axle thread pitch by holding up the threads on your axle to the examples below.
- 3) Measure your axle to determine the length.
- 4) With your thread pitch and length, choose the axle you need from the table.

Thread Pitch:

12 x 1.0

12 x 1.5

12 x 1.75



Axle Length	Thread Pitch	Reference
Between 154 and 172 mm	1,0	BKO213
Between 154 and 172 mm	1,5	BKO204
Between 167 and 174 mm	1,75	BKO201